

MXR micro flanger

LIVE TO PLAY LIVE®



JIMDUNLOP.COM

92503005394revC

**Operation
Manual**

M152 MICRO FLANGER

DESCRIPTION

- Dial in warm and thick flanging for massive sonic “swooshes”
- Two control knobs to adjust speed and regeneration for simple operation
- All analog circuitry with bucket brigade technology for warm analog tone
- True bypass

POWER

The MXR Micro Flanger can be powered by one 9-volt battery (accessed by removing the pedal bottom plate), a 9-volt AC adapter such as the Dunlop ECB003/ECB003E, or a DC Brick™ power supply.

CONTROLS

- RATE knob adjusts the speed of the effect.
- REGENERATION controls the amount of feedback, affecting the effects intensity.
- FOOTSWITCH toggles effect on/ bypass (red LED indicates on)

DIRECTIONS

- Run a cable from your guitar to the Micro Flanger's INPUT jack and run another cable from the Micro Flanger's OUTPUT jack to your amplifier.
- Turn the Micro Flanger's effect on by depressing the footswitch; the red LED will illuminate, indicating that the effect is activated.
- Turn the RATE knob clockwise for a faster flanging effect, counterclockwise for a slower effect. Rotate the REGENERATION knob clockwise for more intensity, and clockwise for a more subtle effect.

SAMPLE SETTINGS

“BARLEY-CUDA”
70's ROCK



“FAST LANE LIFE”
70's POP/ROCK



“BLACK HOLE SOUND”
90's GRUNGE



SPECIFICATIONS

Input Impedance	1 MΩ
Output Impedance	1 kΩ
Max Input Level	-2 dBV, 500 Hz
Max Output Level	+8 dBV
Noise Floor*	-88 dBV
Rate Control	0.2 Hz to 5.5 Hz
Delay Range	3.9 μs to 4 ms
Bypass	True Hardwire
Current Draw	7 mA
Power Supply	9 volts DC

*A-weighted

