

## **LP-10 Firmware Upgrade Procedure**

### **1. Locate the Upgrade Tool**

After downloading the firmware upgrade package (LP10 upgrade\_tool\_desk v1.0.8.zip) on your PC, open the folder.

### **2. Launch the Upgrade Program**

Double-click the file named **upgrade\_desk.exe** to start the upgrade tool.

 *Make sure you have the necessary permissions to run this program (administrator rights may be required).*


### **3. Load the Firmware File**

Download and uncompress the firmware file (.zip or .rar file). Click the **“Browse”** button on the upgrade tool and select the firmware file named

**LP10.LS8.8459.13-1.swu**

(replace LP10.LS8.8459.13-1.swu with other name if you are upgrading with a different firmware)

Once the file is selected, the full file path will appear in the program window. The LP10 device must be in the same local network as the PC.



#### 4. Start the Upgrade


Click “Upgrade” to begin the firmware update process.





## 5. Wait for Completion

The upgrade process consists of **8 steps** and takes approximately **3 -5 minutes** to complete.



After the upgrade is finished, the LP-10 will show 100% upgrade and automatically **reboot**.



## 6. Enjoy Your Music

Once the device restarts successfully, your LP-10 is ready to use with the new firmware.

