

Parts list:

- 18: Small screw
- 19: Larger screw
- 20: Rubber foot
- 3: Top panel
- 4: Side rail
- 5*: Spacer
- 6: Vertical post
- 7: Vertical post
- 8: Vertical post
- 9: Central column
- 10: Column section
- 11: Column section
- 12: Column section
- 13: Small cap
- 14: Small cap
- 15: Small cap
- 16: Tube
- 17: Tube
- 21: L-shaped bracket
- 22: Wedge
- 23: Ring
- 24: Wedge
- 25: Wedge
- 26: Wedge

Dimensions: 47 cm, 47,5 cm

Exploded view showing the assembly of the central column (9) and side rails (4) onto the base panels (1, 2).

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26
1	2	1	1	5	2	2	2	1	1	1	1	2	2	8	2	2	2	2	2	1	4	3	1	1	1

1: Attach the central column (9) to the base panels (1, 2) using posts (6, 7) and caps (13, 14, 15). Insert wedges (22, 24, 25, 26) to secure the column.

2: Attach the side rails (4) to the base panels (1, 2) using posts (15) and caps (13, 14, 15). Insert wedges (22, 24, 25, 26) to secure the rails.

3: Attach the top panel (3) to the side rails (4) using screws (18, 19) and caps (13, 14, 15). Insert wedges (22, 24, 25, 26) to secure the top panel.

4: Rotate the TV stand to the other side to complete the assembly.

5: Attach the rubber feet (20) to the bottom of the stand using screws (18, 19) and caps (13, 14, 15). Insert wedges (22, 24, 25, 26) to secure the feet.

6: Attach the top panel (3) to the side rails (4) using screws (18, 19) and caps (13, 14, 15). Insert wedges (22, 24, 25, 26) to secure the top panel.

7: Attach the rubber feet (20) to the bottom of the stand using screws (18, 19) and caps (13, 14, 15). Insert wedges (22, 24, 25, 26) to secure the feet.

8: Place the TV on the stand.